



REASSEMBLE INSTRUCTIONS

STEELCASE LEAP V2 CHAIR SIDE ACTIVATED CYLINDER


VIDEO GUIDE




To help you properly assemble your Steelcase Leap v2 chair, watch our assembly video by going to bit.ly/3g1oTaQ

PARTS

Please read all instructions carefully before assembly.



BASE WITH CASTERS




SIDE ACTIVATED CYLINDER



TOP HALF OF CHAIR

1



Place chair on its back on a soft surface.
(A) Make sure the tab on the side activated cylinder aligns with the SEAT HEIGHT lever.
(B) Insert it into the hole on the bottom of the chair's mechanism. Verify it is locked in place.

2



Place the five star base on the ground, with the casters touching the floor. Take your chair with the cylinder inserted into the mechanism and slide into base.



Sit in your chair to set the cylinder. Your chair is now ready to use!

RETURN POLICY

Must be returned in the **original box**. Free returns within 30 days. BTOD will waive restocking fees and pick up your item(s) for a full refund at no cost to you. Returns of two or more fall under standard return policy. Outlet items cannot be returned.

QUESTIONS? CONTACT US:

📞 866-733-0698

✉️ INFO@BTOD.COM



12 YEAR
WARRANTY

BTOD.COM
5508 E JELINEK AVE
WESTON WI 54476